



# How We Install: Vent Fittings

Components Required:  
1 x URAO-067 Vent

1.

Vent should be fitted near the peak of the wrapped component.



5.

We then align and place the vent on top of the cut-out...



2.

We cut across (around 2cm long) where vent is to be placed.



6.

...and tape along the sides of the vent ensuring we do not tape seal over the vent outlet.



3.

Then we remove the double-sided tape from the vent...



4.

...and ensure the vent outlet with the 'V' cut-out is facing and sloping downwards.



**The Vent Fitting  
is complete.**